




Faculty of Physics, University of Belgrade

EXAMPLES OF LINE PROFILES FROM LABORATORY PLASMA SIMILAR TO PROFILES FROM ASTROPHYSICAL PLASMAS

J.Purić, N. Cvetanović, B. M. Obradović, I.P. Dojčinović,
M.M. Kuraica

nikola@ff.bg.ac.rs

Plasmas - The 4th State of Matter



Connection between profiles obtained from laboratory and
astrophysical plasmas, similar profiles from different effects?

Stark polarization spectroscopy in the presence of static field in plasma

- Hydrogen lines decomposed in high electric field are observed using polarizer. Wavelength separation is then used for E field measurements.
- Helium lines and their forbidden show sensitivity on electric field both through λ shift and intensity ratio.


Grimm abnormal glow discharge with H₂

$$n_e = 10^{11} - 10^{12} \text{ cm}^{-3}$$

$$T_e \approx 5000 \text{ K}$$

$$T_G \approx 350 \text{ K}$$






Plasma not in equilibrium






Modification of Grim's abnormal glow discharge,


Grimm W., Spectrochim. Acta **23B**,443(1968),

Ferreira et. al, Spectrochim. Acta **35B**,287(1980)



H Balmer lines in the presence of high E – cathode fall of glow discharge






π polarized components of H_{β} line in the cathode fall of Grimm type glow discharge, $U=900$ V, $p=3,8$ mbar

Stark splitting and shifting of three visible HeI lines and their forbidden components is used for measuring the external electric field strength.

HeI 402.6 nm ($2p^3P^0 - 5d^3D^0$),

HeI 447.1 nm ($2p^3P^0 - 4d^3D^0$),


HeI 492.1 ($2p^1P^0 - 4d^1D^0$) lines and their forbidden components ($2p^3P^0 - 5f^3F^0$), ($2p^3P^0 - 4f^3F^0$) and ($2p^1P^0 - 5f^1F^0$)



Wavelength separation of He I lines from their forbidden components

M.M. Kuraica, N. Konjević, Appl. Phys. Lett. 70 (1997) 1521

Peak to peak separation ratio of π polarized He 492.1 nm allowed line and its forbidden component was used for determining the E strength






Doppler spectroscopy of high energy Hydrogen atoms



- High energy atoms, up to 1keV are created in various types of discharges.
- Fast ions are formed in the sheath of the discharge which then undergo charge exchange collision therefore creating fast atoms.
- These atoms are then excited mostly by collisions with bulk gas particles.
- Lines of *H* atom spectra are seen excessively broadened or Doppler shifted due to high velocity 100-500 km/s.

C

Charge exchange





H_2^+



Hollow cathode glow discharge

- Non-thermal
- Low pressure ~ 0.4 mbar, High voltage $\sim 1,5$ kV
- Intensive Doppler shift






DC +

DC -

Intensity (a.u.)




H_α


hollow cathode discharge



$U=1.5$ kV

$\Delta\lambda$ (nm)






Reversed electric field direction





Excessive broadening in Grimm glow discharge






H α


Grimm glow discharge
 $U=2$ kV

Observation orthogonal to the E field


How should we fit this curve ?




Reflection of ions from the cathode




4 Gauss components





3 Gauss components





3 Gauss components




Monte Carlo simulation





Balmer profiles in Electrostatically confined plasma







New experiment results



Plasma accelerator: magneto-plasma compressor MPC



High energy plasma source


$$n_e \approx 10^{17} \text{ cm}^{-3}$$


$$T_e \approx T_{\text{ion}} \approx 20000 \text{ K}$$


Plasma close to equilibrium

Plasma velocity $\sim 100 \text{ km/s}$


$$B \approx 1 \text{ T}$$








Absorption from cold gas: self-reversal




Inhomogeneous plasma – regions with different parameters

First investigations towards simulating absorption in hot emission stars

Gas constitution of 90% Hydrogen, 10% Helium





What may be concluded?

- When investigating laboratory plasma there is the possibility of changing the parameters and ways of observation and then seeing how this influences the spectra
- This may possibly used to test some of the ideas in astrophysics

Thank you for your attention !